

Interpreter Unit Simplified Operation Manual



【Microphone operation】

- ① Select the language to be interpreted displayed on the LCD with the “Channel Select”
- ② The “Microphone” is used to turn the microphone ON/OFF
- ③ Press the “Mute” to temporarily turn off the microphone

【Adjustment of the listening voice】

- ④ The headphone volume can be adjusted
(Alarm for hearing protection is available. Select the model when connecting headphones)
- ⑤ The speaker volume can be adjusted. (The speaker is turned off when the microphone is on)
- ⑥ Adjust the sound quality of the audio to be listened to. (Top knob: high audio, Bottom knob: low audio)
- ⑦ Select the audio to be heard on the speakers

【Selecting the audio for listening】

- ⑧ Select this option to listen to the floor audio (venue audio) only
- ⑨ To listen to the interpreter audio and floor audio, select the language allocated to the channel selector (Used during relay interpreting)

【Other】

- ⑩ This is set to switch between the camera image and content image output from the interpreter unit HDMI connector
- ⑪ Assignable buttons for interpreting support functions such as slow-speak, replay, and video selection