
How to Turn Off the Interpreter Unit


Only the interpretation unit can be turned off

Operate from the server Meeting Application

- The BOSCH **Meeting** Application starts automatically when the server starts up
- · Please operate while watching the display screen in the rack



- ① Press the Power Off on the app screen
- The interpreter unit will turn off.



*To turn on an interpreter unit that has been turned off

Press the power on the app screen

